


# - PCB Informational Meeting - Monitoring for PCBs as Part of TMDL Development and Implementation



Mark Richards

[Mark.richards@deq.virginia.gov](mailto:Mark.richards@deq.virginia.gov)

March 9, 2010

# VA Regulatory Criteria Total PCBs

**Consumption  
Advisories  
Fish Tissue  
(ppb)**

**Water Quality  
Criterion  
(ppb)**

VDH	<b>50</b>		<b>0.00064</b>
-----	-----------	--	----------------

WQC represents concentration in the water column where the bioaccumulation of tPCBs in fish is minimized to be protective of fish consumption (by humans)

# Meeting Overview - PCBs


- **Background**
  - Why important?
- **Legacy Pollutant**
- **TMDL Case Study**
- **Challenges**
- **PCB Point Source Guidance**



# Problem Identification

## - Fish Consumption Advisories -


### Waters Under VDH Fish Consumption Advisories Identified in 2008 305(b)/303(d) Water Quality Integrated Report



Revised November 26, 2007



# PCBs




- Estimated that > 1.5 Billion lbs. manufactured in the U.S. until 1977 - “Legacy Contaminant”
- Very stable and heat resistant
  - Persistent in environment
- Common uses:
  - Transformers, capacitors, hydraulic fluids, circuit breakers, PVC Products, carbonless copy paper, caulking material, paints, etc.



# PCBs – What are They?



- Biphenyl molecule (1-10 chlorine atoms)




Structure of Polychlorinated Biphenyl (PCB) Molecule

- 209 distinct PCB Compounds
- Regulated by VADEQ as Total PCB (tPCB) = 209 compounds summed
- Referred to as PCB Aroclors (Monsanto tradename) = mixture of PCB compounds

# PCBs – Why Important?

- Bioaccumulates at low conc. (lipids)
- Suspected carcinogen
- Other toxicological effects (humans)
  - Immunotoxicity, reproduction and developmental, hepatotoxicity (liver), neurotoxicity, and chloracne
- Major Sources of Exposure (humans)
  - Consumption of contaminated fish
  - Inhalation (dust from contaminated sites)


WQC =  
0.00064 ug/L



Structure of Polychlorinated Biphenyl (PCB) Molecule

# PCBs - A Legacy Pollutant?

- Banned in late 70's
- Accumulate and persist in river sediments from historic releases
  - “Hot Spots”
- Generally not detected under VPDES Program



# PCBs – Current Releases?


- PCBs used many years after banned
- Contaminated sites with active transport (non-point - e.g., CERCLA, RCRA, VRP, unknown)
- Point Sources
- Dielectric oils considered non PCB < 50 ppm
  - Fish advisories at 0.05 ppm
- Inadvertent production
  - Carbon + heat + chlorine
  - Up to 50 ppm allowed (TSCA)
- Atmosphere

NO PCBs



# PCBs – Point Sources


(Mean Concentrations)



# Questions?


# PCB TMDLs

## Roanoke River



## New River

■ PCB Fish Consumption Advisories



Completed December 2009  
& beginning Implementation

Initiating Source  
Assessment



# Components of TMDL Study

Fish Consumption Advisory



Identify Problem

Initiating (New R)



Source Assessment

- Identify sources
- Estimate source loading

**Method 1668**  
Low Level PCB  
Analysis



Link Sources to Targets

- Assess linkages (Model)
- Estimate total loading capacity

**Steps  
completed  
on Roanoke  
River**



TMDL Allocations


- Divide loads among sources

**TMDL = Sum of WLA + Sum of LA + MOS**

# TMDL Source Assessment

## - Load Categories-




- Point Sources
  - WWTPs, Industry, Industrial SW, CSOs
  - MS4
- Non-Regulated Stormwater (Direct Drainage)
- Contaminated Sites
- Atmospheric Deposition
- River Sediment



# PCB TMDL Development

- Roanoke River TMDL Study
  - Ambient monitoring (low detection method)
  - Point Source monitoring (low detection method)
    - Significant point sources
      - Baseline PCB loads developed from real data
    - Industrial Stormwater sources (no data)
      - Baseline loads estimated
  - PCB Point Source Monitoring Guidance under development during Roanoke TMDL study
    - Used to identify potential SW sources

# Upper Roanoke Watershed



# Roanoke River TMDL

## Average annual tPCBs loads for Roanoke River source categories

Source Category	Baseline (mg/yr)	WLA (mg/yr)	LA (mg/yr)	% Reduction
<b>Upper Roanoke River</b>				
VPDES Dischargers	17,665.8	28,267.1		-60.0
Individual Industrial/General Permits	6,827.4	5.3		99.9
MS4	109,622.4	332.7		99.7
Contaminated Sites	7,853.5		1.0	100.0
Urban background (unknown sites)	12,082.4		114.4	99.1
Atmospheric Deposition	8,862.5		8,419.4	5.0
<b>Total</b>	<b>162,914.1</b>	<b>28,605.0</b>	<b>8,534.8</b>	<b>77.2</b>

# Roanoke River TMDL - WLA

Stream	Point sources			Stormwater dischargers			MS4s		
	Baseline (mg/yr)	WLA (mg/yr)	% Reduction	Baseline (mg/yr)	WLA (mg/yr)	% Reduction	Baseline (mg/yr)	WLA (mg/yr)	% Reduction
Upper Roanoke River									
North Fork Roanoke River	10.7	17.8	-66.3	105.5	1.0	99.1	990.5	9.4	99.1
South Fork Roanoke River	68.4	228.6	-234.0	0.0	0.0	0.0	177.4	1.7	99.1
Masons Creek	0.0	0.0	0.0	5.9	0.1	99.1	950.6	9.0	99.1
Peters Creek	90.7	50.8	44.0	1.4	0.0	99.1	1,542.2	14.6	99.1
Tinker Creek	0.0	0.0	0.0	135.6	1.3	99.1	10,799.4	102.6	99.1
Wolf Creek	0.0	0.0	0.0	0.0	0.0	0.0	1,053.7	10.0	99.1
Unnamed Trib to Roanoke River	0.0	0.0	0.0	0.0	0.0	0.0	52.8	0.5	99.1
Roanoke River	17,495.9	27,969.9	-59.9	6,579.0	3.0	100.0	94,055.7	184.8	99.8
Upper Total	17,665.8	28,267.1	-60.0	6,827.4	5.3	99.9	109,622	332.7	99.7

# Point Sources – Non-stormwater

- TMDL requirements:
  - Baseline or existing load condition
  - Waste Load Allocations (WLAs)

$$\text{Baseline PCB Condition (g/yr)} = \left[ \text{PCB conc. ng/L} \right] * \left[ \text{Ave Flow (mgd)} \right] * \text{Conv. Factor}$$

~~~~~

$$\text{TMDL WLA (g/yr)} = \left[ \text{PCB Endpoint conc. conc. ng/L} \right] * \left[ \text{Design Flow (mgd)} \right] * \text{Conv. Factor}$$

# Point Sources – Industrial Stormwater Facilities

- Land based foot-print established (GIS)
- A PCB background soil conc. calculated for different land uses (contaminated sites or urban background)
  - Upper Roanoke urban background (6.8 ng/g)
- Model generated an est. PCB baseline load
  - Input includes local precipitation, area-weighted land use, and PCB soil concentration
- WLA assigned by model
  - Determined amount of PCB reductions necessary to meet TMDL water endpoint instream



# PCB TMDL Implementation

- If baseline PCB load exceeds the TMDL WLA:
  - BMP WQBELs (40 CFR 122.44(k))
    - Numeric effluent limits considered infeasible
    - EPA accepted approach on Potomac River PCB TMDL
  - PCB monitoring (confirm above or below WLA)
  - Pollutant Minimization Plan
  - Adaptive Implementation
    - Objective to back-track source and not treat at end of pipe

# Questions?

# Point Sources


- Permitted dischargers generate PCB data under the VPDES Permit Program using EPA Method 608
  - Typical Comments/Questions
    - “PCBs have never been detected in my effluent.”
    - “Why has my facility been included (or being targeted) in the TMDL?”
    - “Why are permitted dischargers being asked to collect additional PCB data?”

# Point Sources

## TMDL Need - Establish Baseline Loading

- EPA Method 608 (Permit method)
  - PCBs rarely detected (MDL =  $0.065 \mu\text{g/L}$ ; QL =  $0.5 \mu\text{g/L}$ )    tPCB WQC =  $0.00064 \mu\text{g/L}$
  - Reported as Aroclors
- Options
  - No data = no load?
    - Not an option: existing load required by TMDL
  - Use assumptions (Method QL or DL)
  - Generate low level PCB data

# Assumptions vs. Real Data



# PCB Analytical Method

- EPA Method 1668, Revision B
  - High Resolution Gas Chromatography/  
High Resolution Mass Spec
  - Analyzes 209 Congeners
  - Detection  $\leq 5$  pg/L per congener
  - Targets PCB concentrations that are relevant to fish

# **Guidance for Monitoring of Point Sources for TMDL Development Using Low Level PCB Method 1668**

March 2009

<http://www.deq.virginia.gov/tmdl/pcb.html>

# Need for PCB Monitoring Guidance

- All areas of the Commonwealth lacking PCB water data (ambient and effluent)
- DEQ has insufficient funding to perform PCB analysis for TMDL source categories
- Asks VPDES permit holders to generate the data
  - Provides a consistent, technical approach
  - Enables DEQ to focus on performing ambient water and sediment PCB analysis
    - Used for source assessment
    - Model fate and transport of PCBs



# Point Source PCB Monitoring Guidance

**Purpose is to establish procedures for implementing point source monitoring of PCBs in support of TMDL development.**

~~~~~

**Originated from data needs on the Potomac PCB TMDL. Similar to efforts used in New York (Panero *et al.*, 2005), Delaware and New Jersey (DRBC 1998)**

<http://www.nyas.org/programs/harbor.asp>

<http://www.state.nj.us/drbc/regs/pcb-new.pdf>

# Guidance Developmental History

2006 - DEQ Internal Development

2007 thru 2008 –

Technical Advisory Committee: Bluefield STP, City of Richmond, Dominion Resources, DCR, DMME, HRPDC, Navy, Southern Environmental Law Center, UOSA, U.S. Fish & Wildlife, VAWMA, VMA, Western VA Water Authority (6 meetings)

DEQ Internal Review (dynamic)

EPA Region III review (Fall 2008)

2009 - Finalized

# Guidance Document

- I. Introduction
- II. Background
- III. Authority
- IV. Definitions
- V. Procedure
  - A. Facilities identified for monitoring
  - B. Monitoring frequency
  - C. Sample collection and analytical requirements
  - D. Analytical laboratories
  - E. PCB reporting requirements
  - F. References
- VI. Appendices

# **VADEQ RO Identifies Facilities Considered for PCB Monitoring (per PCB Guidance)**

- Major (including CSOs) & minor municipals
- Industrial facilities (specific SIC codes)
- Industrial stormwater dischargers under individual or general permits (SIC codes)
  - Exemptions (case by case basis)
    - Minor municipals – document not a source
    - SW through a POTW or CSO or “no exposure”
    - Representative or identical outfalls
    - DEQ does not regulate MS4s (DCR)
      - Provides framework for PCB monitoring

# Monitoring Frequency

Base flow (dry) and storm flow (wet) needed for load characterization

VPDES Facility				
Municipals		Industrials		
Major $\geq 1$ MGD	Minor < 1 MGD	Process wastewater only	Process wastewater with storm water	Storm water only
2 wet + 2 dry	1 wet + 1 dry	2 samples (storm event sampling not required)	1 dry + 1 wet	2 wet

If PCB reductions unnecessary under a TMDL, there is no need for additional PCB monitoring

# PCB Guidance Appendices

- Appendix C
  - Sampling options & “clean technique” protocol
- Appendix D
  - Analytical Requirements (EPA Method 1668)
  - Approved list of laboratories on website
- Appendix E
  - Data Submittal Requirements

# Lessons Learned

- Samples must be collected as described in Appendix C
  - Since dealing with low level analysis, very easy to contaminate sample
  - Recommended sampling containers be obtained from laboratory
- If analysis is not performed in accordance with requirements specified in Appendix D, not worth running the analysis
  - Reporting levels not met

# Cost Containment

- Analytical Costs
  - \$700 - \$1,200 per sample
  - Encourage partnerships between facilities
    - Samples run in batches of 20
    - Samples can be held under the proper conditions up to one year
    - Cost savings
  - Some laboratories are willing to coordinate analytical work among facilities



Virginia DEQ - TMDLs - PCB resources - Mozilla Firefox

File Edit View History Bookmarks Tools Help

< >

↺

✕

🏠

📄

http://www.deq.virginia.gov/tmdl/pcb.html

☆

👤

Google

🔍

Most Visited Getting Started Latest Headlines

Virginia DEQ - TMDLs - PCB resources Virginia DEQ - TMDLs - PCB resour...

DEQ

VIRGINIA DEPARTMENT OF ENVIRONMENTAL QUALITY

Search DEQ

Go

Virginia DEQ :: TMDL :: PCB resources

Main Menu

TMDL Home

TMDL development

TMDL implementation

Geospatial data

Chesapeake Bay TMDL

PCB TMDLs

TMDL ad hoc committee

Additional information

DEQ water programs

Resources for PCB TMDLs




Email: [Charles Martin](#)

Regulation

Public Notices

Guidance

Contacts



- [Guidance for Monitoring of Point Sources for TMDL Development Using Low-Level PCB Method 1668](#)
- The VDEQ issued a statewide strategy in January 2005 to address PCB contamination in the waters of the Commonwealth: [PCB Strategy Report](#)
- [PCB Laboratories](#)
- [Advisory Committee Meeting and PCB Guidance Materials](#)
- [Electronic Deliverable Data \(EDD\) files available for download in accordance with the PBC Point Source](#)

# Questions?

**Presentation & PCB Guidance Available  
at**

**<http://www.deq.virginia.gov/tmdl/pcb.html>**

**[Mark.richards@deq.virginia.gov](mailto:Mark.richards@deq.virginia.gov)**